

- 1. Set up test arrangement as shown.
- 2. Tighten trimmer screws on top of A-1381 by turning screw CCW. Frequ ncy should be approximately 16.2 KC.
- 3. Loosen trimmer screw 2 turns. Frequency should be approximately 18.0 KC.
- 4. Set trimmer screw to 17.0 KC.
- 5. Measure D.C. voltage on terminal 3 of A-1381. Should be approximately -40 Volts.
- 6. Measure A.C. voltage on terminal 1 of A-1381 . Should be approximately 10 volts.

