

PROCEDURE:

- 1. Connect PBX Extension on Switchboard to another local.
- 2. Listen to SBE-2 output on Receiver.
- 3. Adjust line balance for minimum output of audio into the Hybrid ''Rx'' terminals.
- 4. Set the 1000 ohms potentiometer for minimum and strap the condensers in the Hybrid Unit, as required, to obtain line balance for crosstalk to be attenuated 40 db or more.
- 5. Telephone conversation should permit 100% modulation of the SBE-2 and the audio should easily be heard on the telephone.

Note:

DB figures above were those obtained in test.