

REQ	ITEM	PART NUMBER	BREAKOUT		DESTINATION OR DESCRIPTION	
			FROM	TO	FROM	TO
40		LWC26(7)U8	6-11	5-11	XA14 PIN11	XA15 PIN11
41		8	5-11	4-11	XA15 PIN11	XA16 PIN11
42		8	4-11	3-11	XA16 PIN11	XA17 PIN11
43		8	3-11	2-11	XA17 PIN11	XA18 PIN11
44		8	2-11	7-B	XA18 PIN11	J2 PIN V
45		98	6-13	5-13	XA14 PIN13	XA15 PIN13
46		98	5-13	4-13	XA15 PIN13	XA16 PIN13
47		98	4-13	3-13	XA16 PIN13	XA17 PIN13
48		98	3-13	2-13	XA17 PIN13	XA18 PIN13
49		98	2-13	7-B	XA18 PIN13	J2 PIN W
50		9	6-13	5-13	XA14 PIN12	XA15 PIN12
51		9	5-13	4-13	XA15 PIN12	XA16 PIN12
52		9	4-13	3-13	XA16 PIN12	XA17 PIN12
53		9	3-13	2-13	XA17 PIN12	XA18 PIN12
54		9	2-13	7-B	XA18 PIN12	J2 PIN X
55		93	6-15	5-15	XA14 PIN16	XA15 PIN16
56		93	5-15	4-15	XA15 PIN16	XA16 PIN16
57		93	4-15	3-15	XA16 PIN16	XA17 PIN16
58		93	3-15	2-15	XA17 PIN16	XA18 PIN16
59		93	2-15	1-15	XA18 PIN16	XA19 PIN16
60		93	1-15	8-A	XA19 PIN16	J8 PIN G
61		94	6-19	5-19	XA14 PIN18	XA15 PIN18
62		94	5-19	4-19	XA15 PIN18	XA16 PIN18
63		94	4-19	3-19	XA16 PIN18	XA17 PIN18
64		94	3-19	2-19	XA17 PIN18	XA18 PIN18
65		94	2-19	1-19	XA18 PIN18	XA19 PIN18
66		94	1-19	8-A	XA19 PIN18	J8 PIN H
67		95	6-19	5-19	XA14 PIN19	XA15 PIN19
68		95	5-19	4-19	XA15 PIN19	XA16 PIN19
69		95	4-19	3-19	XA16 PIN19	XA17 PIN19
70		95	3-19	2-19	XA17 PIN19	XA18 PIN19
71		95	2-19	1-19	XA18 PIN19	XA19 PIN19
72		95	1-19	8-A	XA19 PIN19	J8 PIN J
73		92	6-15	5-15	XA14 PIN15	XA15 PIN15
74		92	5-15	4-15	XA15 PIN15	XA16 PIN15
75		92	4-15	3-15	XA16 PIN15	XA17 PIN15
76		92	3-15	2-15	XA17 PIN15	XA18 PIN15
77		92	2-15	1-15	XA18 PIN15	XA19 PIN15
78		LWC26(7)U92	1-15	8-A	XA19 PIN15	J8 PIN K