

REQ	ITEM	PART NUMBER	BREAKOUT		DESTINATION OR DESCRIPTION	
			FROM	TO	FROM	TO
	1	LWC26(7)04	1	31	XA19 PIN X	XA13 PIN I G
	2	↑	1	31	XA19 PIN V	XA13 PIN I 5
	3	4	2	26	XA18 PIN X	XA 8 PIN H
	4	3	2	26	XA18 PIN V	XA 8 PIN F
	5	5	2	26	XA18 PIN T	XA 8 PIN L
	6	1	2	26	XA18 PIN S	XA 8 PIN K
	7	94	4	24	XA17 PIN X	XA 7 PIN D
	8	93	4	24	XA17 PIN V	XA 7 PIN C
	9	95	4	24	XA17 PIN T	XA 7 PIN E
	10	91	4	24	XA17 PIN S	XA 7 PIN F
	11	4	6	24	XA16 PIN X	XA 7 PIN V
	12	3	6	24	XA16 PIN V	XA 7 PIN U
	13	5	6	24	XA16 PIN T	XA 7 PIN W
	14	1	6	24	XA16 PIN S	XA 7 PIN X
	15	94	7	22	XA15 PIN X	XA 6 PIN V
	16	93	7	22	XA15 PIN V	XA 6 PIN U
	17	95	7	22	XA15 PIN T	XA 6 PIN W
	18	91	7	22	XA15 PIN S	XA 6 PIN X
	19	4	8	22	XA14 PIN X	XA 6 PIN D
	20	3	8	22	XA14 PIN V	XA 6 PIN C
	21	5	8	22	XA14 PIN T	XA 6 PIN E
	22	LWC26(7)01	8	22	XA14 PIN S	XA 6 PIN F
	23	MWC24(7)01	15	16	T1 PIN G	XA 2 PIN X
	24	3	15	16	T1 PIN 7	XA 2 PIN P
	25	4	15	16	T1 PIN 8	XA 2 PIN N
	26	5	15	16	T1 PIN 9	XA 2 PIN H
	27	6	15	16	T1 PIN 10	XA 2 PIN F
	28	MWC24(7)07	14	16	T1 PIN 5	XA 2 PIN Y
	29	MWC22(7)098	14	13	T1 PIN 4	POWER SWITCH
	30	90	14	13	T1 PIN 1	POWER SWITCH
	31	98	13	11	POWER SWITCH	XF2 - SIDE
	32	90	13	10	POWER SWITCH	XF1 - SIDE
	33	98	11	33	XF2 - REAR	FL 2
	34	MWC22(7)090	10	33	XF1 - REAR	FL 1
	35	NOT USED				
	36	LWC26(7)091	16	5	XA2 PIN A	XDS-2
	37	LWC26(7)091	5	3	XDS-2	XDS-1
	38	LWC26(7)090	5	17	XDS-2	XA 3 PIN 4
	39	LWC26(7)095	3	17	XDS-1	XA 3 PIN 20
	40	MWC24(7)091	16	35	XA 2 PIN 4	Q1 COLLECTOR