

CA

EQ	ITEM	PART NUMBER	BREAKOUT		DESTINATION OR DESCRIPTION	TO
			FROM	TO		
	39	MWC 22(7)U0	9	6	(PROG)TB101 SYSTEM GND	J3-22
	40	MWC 22(7)U0	9	7	↑ ↑ ↑	J2-1
	41	MWC 22(7)U0	9	5	(PROG)TB101 SYSTEM GND	J1-1
	42	LWC 24(7)U94	4	5	TB106-6	INTFC } TONE IN
	43	↑	4	5	TB106-7	INTFC }
	44	5	4	8	↑	J1-C
	45	6	4	8	↑	J1-4
	46	91	4	8	↑	J1-3
	47	LWC 24(7)U92	4	8	↑	J1-5
	48	MWC 20(7)U91	4	9	↑	(PROG)TB101 GND - SUPPLY
	49	MWC 20(7)U8	4	6	TB106-14	J3-U ON REC VOLTS
	50	LWC 24(7)U9	2	7	TB105-1	J2-10
	51	↑	2	7	↑ -2	J2-8
	52	3	2	7	↑ -3	J2-7
	53	4	2	7	↑ -4	J2-9
	54	5	2	7	↑ -5	J2-14
	55	96	2	7	↑ -6	J2-12
	56	7	2	7	↑ -7	J2-11
	57	98	2	7	↑ -8	J2-13
	58	9	2	6	↑ -9	J3-8
	59	91	2	6	↑ -10	J3-9
	60	92	2	6	↑ -11	J3-6
	61	93	2	6	↑ -12	J3-7
	62	94	2	6	↑ -13	J3-C
	63	95	2	6	↑ -14	J3-8
	64	6	2	6	↑ -15	J3-D
	65	97	2	6	TB105-16	J3-E
	66	1	3	6	TB103-1	J3-18
	67	92	3	6	↑ -2	J3-M
	68	93	3	6	↑ -3	J3-L
	69	4	3	6	↑ -4	J3-19
	70	95	3	6	↑ -5	J3-20
	71	6	3	6	↑ -6	J3-21
	72	7	3	8	↑ -7	J1-F
	73	8	3	8	↑ -8	J1-H
	74	9	3	8	↑ -9	J1-U
	75	91	3	8	↑ -10	J1-19
	76	LWC 24(7)U92	3	8	TB103-11	J1-T