	7. 1963 or7	TMC SPECIFICATION NO. S-745	
JS Compiled	CHECKED	TITLE:	
APPR	OVED A	7	

SBT-350 M & N TEST PROCEDURE

DATE January 17, 1963

SHEET 2 OF 7

JS COMPILED CHECKED

TMC SPECIFICATION NO. S-745

TITLE: SBT-350 M & N TEST PROCEDURE

APPROVED

NOTE: THIS SPEC IS APPLICABLE TO THE SBT-350 M & N. THE ONLY DIFFERENCE BEING THE SBT-350 M USES THE SBE-2, AND THE SBT-350 N USES THE SBE-3.

A. INTRODUCTION

The SBT-350 M is a general purpose radio transmitter system providing SSB, LSB, DSB, AM, FAX, FSK, and CW operation throughout a frequency range of 2 to 32 MC. The rated power output of this unit is 350 WATTS PEP and 200 WATTS CW.

B. MAIN COMPONENTS

The SBT-350 M consists of separate units integrated to form the transmitter system. These components are:

- 1. Rack Assembly RAK-19G.
- 2. Auxiliary Power Panel APP-5.
- 3. Power Supply PSP-350.
- 4. Linear RF Amplifier RFA-1.
- 5. Mode Selector SBE-2.
- 6. Tone Intelligence Unit TIS-3.
- 7. Standing Wave Ratio Indicator SWR-1K.

C. TEST PROCEDURE

The test procedure for the SBT-350S system is outlined on the following pages. Before the system can be tested correctly, all components except the RAK-19G rack assembly, must be tested and passed by the Test Department as per the specific test requirements for each unit.

DATE January 17, 1963

SHEET 3 OF 7

JS

COMPILED

TMC SPECIFICATION NO. S-745

TITLE: SBT-350 M & N TEST PROCEDURE

APPROVED

I. EQUIPMENT REQUIRED

- 1. 52 ohm dummy load, 500W dissipation.
- 2. AC power cable.
- 3. Test equipment rack TMC Model PTE.
- 4. RF output cable, RG-8/U.
- 5. MWC24(7)S3, cable insulated shielded, 5 ft.
- 6. CA-409 cable assembly, jumper 6 in.
- 7. H.P. VIVM, Model 410B, or equivalent.
- 8. Test cable assembly #106.
- 9. Test Chart, SBT-350 MA (S- , Page 7, 2 size dwg.).
- 10. Voltmeter, Simpson 260 or equivalent, (VOM).
- 11. Square Wave Generator, Boonton Model 71.
- 12. Receiver GPR 90, or equivalent.

II. PROCEDURE

- 1. Install AC input power cable from J-701 of RAK-19 to AC line.
- 2. Connect Fanning strips of test cable assembly to E-502 on rear of APP-5 chassis.
- 3. Connect shielded lead from output of TTG mounted in test equipment rack PTE to CHANNEL 1 and CHANNEL 2 input terminals on test cable assembly.
- 4. Connect dummy load MONITOR OUTPUT to SIGNAL INPUT jack of PTE analyzer.
- 5. Connect cable from OUTPUT jack of RFA to dummy load input. Connect H.P. VTVM across load.
- 6. Connect jumper from terminal 5 on test cable terminal board T-601 to terminal 8. This completes external interlock circuit.
- 7. Connect a jumper from terminal 21, T-602 to terminal 22. This completes the KEY LINE circuit to the SBE.
- 8. Set MAIN POWER switch on APP-5 to ON position. The red MAIN POWER indicator lamp should light, and rack blowers should start running.

DATE January	17. 1963
SHEET 4	OF
JS Compiled	CHECKED

TMC SPECIFICATION NO. S-745

TITLE: SBT-350 M & N TEST PROCEDURE

APPROVED

- 9. Set MAIN LINE switch on PSP-350 to ON position. The MAIN POWER indicator lamp should light and RFA-1 blower should start running. NOTE: PSP-350 TRANSMITTER PLATES switch should be in STANDBY-REMOTE position, HV LINE switch in OFF position.
- Turn on POWER switch on SBE. The red lamp on power supply and OVEN lamo should light.
- 11. After a warm-up time of approximately 5 minutes, set the TRANSMITTER PLATES switch to ON position. The indicator lamp should light. The HV LINE OVERLOAD indicator should also light. Set TRANSMITTER PLATES switch to STANDBY-REMOTE position.
- 12. Set XMTR switch on SBE to ON position. The TRANSMITTER PLATES & HV LINE OVERLOAD indicator lamps on PSP-350 should light.
- 13. With SBE MF XTAL SW in the required position, adjust the SBE for two tone test at required output frequency using the TTG supplied with the PTE test equipment rack.
- 14. Set SBE OUTPUT control to zero.
- Set HV LINE switch on PSP-350 to ON position. Red indicator should light and amber OVERLOAD indicator should go out.
- 16. Using the tuning chart, adjust the RFA-1 for 350W PEP at required frequency (132 VRMS across 52 ohms).
- 17. Adjust RFA-1 to obtain 40 db third order distortion at 350W PEP.
- 18. Adjust RFA-1 to obtain 200W CW. (100 VRMS @ 52 ohms.)
- 19. Place VOM across terminals 3 and 4 of T-601 on test cable. Meter should read 115 volts A-C. This is transmitter antenna relay voltage, and may vary +10%.
- 20. With voltmeter connected as in (23) above, set XMTR switch and EXCITER on SBE to OFF position.
 - a. Voltmeter should read zero volts.
 - b. HV LINE and TRANSMITTER PLATES indicators on PSP-350 should go out.
- 21. Place a jumper across terminals 1 and 2 on T-601. TRANSMITTER PLATES and HV LINE indicators should light. Remove jumper.
- 22. Place a jumper across terminals 9 and 10 on T-601. TRANSMITTER VOLTAGES, FINAL VOLTAGES and EXCITER ON indicators should light. Remove jumper.

DATE January SHEET 5	17, 1963 or7	TMC SPECIFICATION NO. S -745									
JS COMPILED	CHECKED	TITLE: SBT-350 M & N TEST PROCEDURE									
APPRO	OVED										

23. Place an ohmmeter across terminals 24 and 25 on T-602. The ohmmeter should read 10 ohms +20% between 24 and 25, ** between 23 and 24.

Place a jumper across terminals 9 and 10 to key the unit. An ohmmeter connected between 23 and 24 should read 10 ohms $\pm 20\%$, between 24 and 25 should read $\frac{10}{2}$.

- 24. Turn the LEVEL ADJ. knob on the TIS-3 maximum clockwise.
- 25. Set the SHIFT CPS indicator to 850.
- 26. Turn the FUNCTION selector switch to the CW position.
- 27. Turn the CENTER FREQUENCY CPS selector switch to the 2000 position.
- 28. Turn the TEST selector switch to the LINE position.
- 29. Turn the KEY MODE selector switch to the 50V position.
- 30. Set the MULTIPLY by frequency selector on the SQUARE WAVE GENERATOR to 1 position.
- 31. Turn the CYCLES frequency selector maximum counter-clockwise and observe fluctuating meter reading.
- 32. Turn the control knob under the PEAK VOLTS meter maximum counter-clockwise.
- 33. Set the small OUTPUT selector switch to the 50 position.
- 34. Connect a piece of 2 conductor shielded cable from the two uppermost S.W. output terminals on the SQUARE WAVE GENERATOR to the test cable assembly terminal board T-602 so that the upper S.W. output terminal is connected to terminal 27 on T-602 and the other S.W. output terminal connected to terminal 29 on T-602.
- 35. Set the B+ switch on TIS-3 to the ON position. The red B+ indicator should light.
- 36. Set the EXCITER switches CHANNEL 1 and CHANNEL 2 to the FSK FAX CW position.
- 37. Increase the LEVEL ADJ. knob for a fluctuating meter indication approximately one third full scale reading.
- 38. Adjust the LSB section of the SBE for an indication of a fluctuating input on both CHANNEL 1 and CHANNEL 2. Turn LSB section OFF.
- 39. Adjust the USB section of the SBE for an indication of a fluctuating input on both CHANNEL 1 and CHANNEL 2. Adjust USB GAIN control for approximately 1/3 scale deflection.

DATE JE	muary	17, 19	63
SHEET_	6	OF	7
COMPIL	JS ED	CHEC	N P

TMC SPECIFICATION NO. 5 -745

TITLE: SBT-350 M & N TEST PROCEDURE

APPROVED

- 40_ Set up test receiver to receive test frequency BFO on.
- Adjust SBT-350 M system for approximately 200 watts CW at test frequency using USB. CHANNEL 1 or CHANNEL 2.
- 42. A keyed 1 KC tone should be heard on the receiver.
- 43. Reduce transmitter output to zero.
- 44. Turn FUNCTION selector switch on TIS-3 to the FSK position.
- Increase transmitter output to 200 watts. A varying tone above and below the center frequency should be heard.
- 46. Vary the CENTER FREQ. CPS selector between 2550 and 1900 and listen for changes in pitch of varying tone. Set switch back to 2000.
- Vary the SHIFT CPS indicator to a lower value and note a narrower shift above and below the center frequency.
- Reduce transmitter output to zero. 48.
- 49. Change the small OUTPUT selector on the SQUARE WAVE GENERATOR to the 10 position.
- 50. Disconnect the wires from terminals 27 and 29 of test cable assembly and connect to terminals 31 and 32. This connects the generator to the FAX input.
- 51. Set the FUNCTION selector switch on the TIS-3 to the FAX position.
- 52. Increase transmitter output to 200 watts. A varying tone should be heard.
- Reverse the output leads at the SQUARE WAVE GENERATOR and note a change in frequency of output tone of receiver.
- 54. Reduce transmitter output to zero.
- 55. Turn off all power switches and reduce all gain controls to zero. Remove AC connections to line.
- Check cables, hardware and slides for ease of movement. Units should tilt without obstruction.
- 57. This completes testing of system SBT-350 M.

	THE CONTENTS	OF THIS	DRAWING AR	RE THE EXCLUSIV	E PROPERTY	<u></u>			TES	г снант	SBT-350 M &	N							
	of the technical material corp. Its unauthorized use or reproduction in whole or in part is strictly forbidden. SBT-350 M S r. No.						RFA Ser. No			SBI	SBE-3 Ser. No								
							\mathbf{or}				TIS		٥		PSI				
7	DATE TEST I	R V																	
OF	IEST 1	,,				SWR-	lK Se	r. No			SBE-2	Ser. N	0		AFI	-5	ber. No.		
45 I 7																			
S -745 SHEET 7						į													
ינט נט					350 WATT	TS PEP, SSB					@)	200 WAT	00 WATTS, CW						
FREQ MC		SBE BAND		Ist AMPL. TUNE		PA TUNING	PA LOADING		MA, PA PLATE HCURRENT	MA, IA SCREEN CURREN	DISTORTIO	MA, PA PLATE CURRENT	SCREEN	POWER	REFLECT POWER WATTS		REMARI	KS	
									and the second s										
															 		-		
NOTE: 1. 350W, PEP, IS 132 VRMS ACROSS 52 ohm LOAD. 2. 200W CW, IS 100 VRMS ACROSS 52 ohm LOAD. ITEM A.C. POWER TO APP-5 2. A.C. POWER TO SBE- 4. A.C. POWER TO TIS 5. INTERLOCK CIRCUITS 6. KEY LINE CIRCUIT 7. CHANNEL 1 CIRCUIT 8. CHANNEL 2 CIRCUIT 9. REMOTE XMTR PLATE CIRCUTT 10. 115V ANTENNA RELAY																			
													PEO ITEM	PART	NO.		DESCRIPT	TION	SYMBOL
											1160	THE TECHNICAL MATERIEL CORP.							
												STOCK SIZE			MAMARONE	CK, NEW YORK			
												S- 745 SHEET 7 OF 7							
	<u> </u>	DESCRIP	TION	DATE	CH. NO. DRA	AFTS CHECKER	ENG. APP.							MATERIAL		TEST PRO	CRODE C	HART SET-350	M & N
SYM	UNLESS O		SPECIFIED:	SCAL		1		<u> </u>					TVDE A TE	MPER HEAT TI	REAT, SPEC	DRAWN	CHECKED	FINAL APPRO	/AL
DIME	NSIONS ARE IN	INCHES			MUM ALLOWAB			0.	DE!	SECTION	ASS'Y. NO.	DATE	ITE & IEI	ar an Inserin			<u> </u>		
	RANCES ON	ECIMALS ±	:,005 ANG	WILL	BE CAUSE FOR	REJECTION.	PE	R	DEL		O ON		FIN	IISH & SPEC. N	10. E	LEC. DES. APP.	MECH. DES, APP.		NO. 1020 36848