
NOTE: Y111 THRU Y120 SUPPLIED ONLY ON CUSTOMERS REQUEST.
NOTE: ALL CAPACITORS ON S108C ARE 1-60 UUF
NOTE – FOR 230VAC OPERATION REMOVE JUMPERS MARKED —x— FROM TB101 AND ADD JUMPERS SHOWN IN DOTTED LINES.
(S108A,B) BAND MCS (HF OSC. SWITCH)
(C181A,B,C) OUTPUT TUNING
UNLESS OTHERWISE SPECIFIED
1- ALL RESISTORS ARE 1/2 WATT. K=1000 M=MILLION
2- ALL CAPACITORS ARE IN MICROFARADS.
3- ALL COILS ARE IN MICROHENRIES. MH=MILLIHENRIES
4- ALL ROTARY SWITCHES ARE SHOWN IN POSITION 1.
MODEL A-1397 POWER SUPPLY
MODEL SBE-3
MODEL AO-101-8,9,10 EXCITER UNIT
SEE SHEET 1
FROM V110
FROM S109
FROM C164
FROM R237
FROM S106D
FROM C257
TO J109
TO C213
TO C221
TO R159
TO R160
TO C241
TO R139
TO C202
TO C214
TO C215
TO C217
TO C218
TO C219
TO C220
TO C221
TO C222
TO C223
TO C224
TO C225
TO C226
TO C227
TO C228
TO C229
TO C230
TO C231
TO C232
TO C233
TO C234
TO C235
TO C236
TO C237
TO C238
TO C239
TO C240
TO C242
TO C243
TO C244
TO C245
TO C246
TO C247
TO C248
TO C249
TO C256
TO C257
TO C258
TO C259
TO C260
TO C307
TO C308
TO C309
TO C310
TO C311
TO C312
TO C313
TO C314
TO C315
TO C316
TO C317
TO C318
TO C319
TO C320
TO C321
TO C322
TO C323
TO C324
TO C325
TO C326
TO