TMC SPECIFICATION NO. S 535

COMPILED BY

TITLE: TEST PROCEDURE SBT-1KC

APPROVED

APPROVED

APPROVED

TO SPECIFICATION NO. S 535

JOB

## A. INTRODUCTION

The SBT-1KC is a general purpose radio transmitter providing FS and CW operation throughout a frequency range of 2 to 32 megacycles at an output power of 1KW.

## B. MAIN COMPONENTS

The SBT-1KC consists of 8 separate units integrated to form the system. These units are:

1. RACK ASS'Y. RAK-9C

2. STANDING WAVE RATIO INDICATOR SWR-1K

3. LINEAR POWER AMPLIFIER RFD-1

4. AUXILIARY POWER PANEL APP-4

5. FREQUENCY SHIFT EXCITER XFK

6. VARIABLE FREQUENCY OSCILLATOR VOX

7. LOW VOLTAGE POWER SUPPLY P.S.-4

8. HIGH VOLTAGE POWER SUPPLY P.S.-5

## C. TEST PROCEDURE

The test procedure for the SBT-1KC system is outlined on the following pages. Before the system can be tested correct-ly, all components except the RAK-9C rack assembly must be tested and passed by the test department as per the specific test requirements for each unit.

## 1. EQUIPMENT REQUIRED

- 1. 52 ohm load, 1KW dissipation.
- 2. AC input power cable.
- 3. RF output cables, RG-8/U.
- 4. HP VTVM, Model 1 410B.

DATE $\frac{2-14-61}{5}$ SH. $\frac{2}{5}$ COMPILED BY		TMC	SPECIFICATION	NO.	<b>S</b> 535	
	TITLE:	TEST PRO	CEDURE SBT-1KC	· · · · · · · · · · · · · · · · · · ·	JOB	_
APPROVED On Val	?				<u> </u>	-

Kilu Kili

- 5. Test chart, SBT-1KC (sheet 5 of S-535).
- 6. Square Wave Generator, Boonton Model 71.
- Two, (2) conductor shielded cables.

Receiver, GPR-90

## II. PROCEDURE

- 1. Connect a jumper between terminals 5 and 8 on the rear of the APP-4 chassis. This completes the external interlock circuit.
- Connect RF output cable from J609 on AX-198 assembly to RF input terminal of dummy load.
- 3. Check that the RF cable interlock on the AX-198 is closed.
- Set MAIN POWER switch on APP-4 to ON position. MAIN POWER indicator lamp should light.
- Set MAIN POWER switch on PS-4 to ON position. 5. The green MAIN POWER indicator lamp should light and RFD-1 blower and PS-5 fan should start running. PS-4 TRANSMITTER VOLTAGES switch should be in STANDBY position; FINAL VOLTAGES switch on OFF position and OVERLOAD breakers in ON position. Adjust line voltage to 115 volts, rack fan should start running.
- 6. After a warm-up time of approximately 5 minutes, set the TRANSMITTER VOLTAGES switch to ON position. indicator lamp should light.
- 7. Set the FINAL VOLTAGES switch to ON position. The red indicator should light and approximately 220 MA of plate current should appear on the PA PLATE CURRENT meter on the RFD.
- Place voltmeter across terminals 3 and 4 of E501 on rear 8. Meter should read 115 volts A.C. This is transmitter antenna relay voltage, and may vary ± 10%.
- With voltmeter connected as in (15) above, set XMTR VOLTAGES switch on PS-4 to STANDBY POSITION.
  - Voltmeter should read zero volts.
  - FINAL VOLTAGES and TRANSMITTER VOLTAGES indicators on b. P.S.-4 should go out. Remove meter.

DATE 2-14-61 SH. 3 OF 5 COMPILED BY		TMC	SPECIFICATION	NO.	<b>\$</b> 535	
COMPILED BI	TITLE:	TEST PRO	CEDURE SBT-1KC		JOB	
APPROVED PK	ł –				<del></del>	

PROCEDURE CONT'D.

# 10. Place a jumper across terminals 1 and 2 on T601. TRANSMITTER VOLTAGES and FINAL VOLTAGES indicator should light. Remove jumper. This checks the REMOTE XMTR PLATE circuit to the P.S.-4.

- 11. Place an ohmmeter across terminals 24 and 25 E502. The ohmmeter should read 10 ohm  $\pm$  10% between 24 and 25 and between 23 and 24.
- 12. Place a jumper across terminals 1 and 2 to key the unit.

  An ohmmeter connected between 23 and 24 should read 10 ohm

  ± 20%; between 24 and 25 should read

  Remove jumper and meter.
- 13. Set POWER switch on the XFK to ON position. POWER and xtal indicators should light.
- 14. Place a jumper across terminals 27 and 28 on the APP-4 chassis. This completes the KEY circuit to the XFK.
- 15. Set POWER switch on the VOX to ON position.
- 16. Turn METER switch on the VOX to the HFO position.
- 17. With the XFK XTAL switch in the EXT. position and MODE switch in CW, adjust the POWER control for about 25MA on XFK PA PLATE CURRENT meter.
- 18. Turn the VOX OUTPUT control to minimum output.
- 19. Set the TRANSMITTER VOLTAGES switch on the P.S.-4 to the ON position. The FINAL VOLTAGES and TRANSMITTER VOLTAGES indicators should light.
- 20. Using the VOX, XFK AND RFD-1, adjust the system for 1KW, CW, at test frequency. (See chart).
- 21. Reduce transmitter output to zero and set TRANSMITTER VOLTAGES switch to STANDBY position.
- 22. Connect a piece of 2 conductor shielded cable from the two uppermost S.W. output terminals on the SQUARE WAVE GENERATOR to the rear of APP-4 chassis terminal board E502 so that the upper S.W. output terminal is connected to terminal 32 on E502 and the S.W. output terminal connected to terminal 31 on E502.

DATE 2-14-61 TMC SPECIFICATION NO. S 535 4 **OF** 5 COMPILED BY TITLE

TOB

APPROVED

#### PROCEDURE CONT'D.

23. Set the MULTIPLY BY frequency selector on the SQUARE WAVE GENERATOR to 1 position.

TEST PROCEDURE SBT-1KC

- 24. Turn the CYCLES frequency selector maximum counter-clockwise and observe fluctuating meter reading.
- 25. Turn the control knob under the PEAK VOLTS meter maximum counter-clockwise.
- 26. Set the small OUTPUT selector switch to the 50 position.
- 27. Turn the MODE selector switch on the XFK to "L" (LINE) position.
- 28. Set the FREQUENCY control to 0 CPS.
- 29. Set the FREQUENCY SHIFT CPS control to 850.
- 30. Set up test receiver to receive test frequency.
- 31. Adjust SBT-1KC for 1KW output at test frequency. A varying tone above and below the center frequency should be heard.
- 32. Reduce the FREQUENCY SHIFT CPS indicator to a lower value. A narrower shift should be heard.
- 33. Reduce transmitter output to zero.
- 34. Change the small OUTPUT selector on the SQUARE WAVE GENERATOR to the 10 position.
- 35. Disconnect the wires from terminals 31 and 32 of test cable assembly and connect to terminals 27 and 29. This connects the generator to the FAX input.
- 36. Set the MODE selector switch on the XFK to the FAX position.
- 37. Increase transmitter output to 1000 watts. A varying tone should be heard.
- 38. Reverse the output leads at the SQUARE WAVE GENERATOR and note a change in frequency of output tone of receiver.
- 39. Reduce transmitter output to zero.
- 40. Turn off all power switches and reduce all gain controls to zero. Remove AC connections to line. Remove all test equipment and cables. This completes operational testing of system SBT-1KC. Check cables, hardware and slides for ease of movement. Units should tilt without obstruction. This completes testing of system SBT-1KC.

	TEST CHART SBT-1KC																	
5	DATE			The state of the s	SBT	-1KC ser	. no			RFD	ser.	no.		P	.S4Aser.	no.		
of	TEST	ву			SWF	-1K ser	. no	<u> </u>		VOX-	3 ser.	no.		P	.S5 ser.	no		
10H										XFK	ser.	no.	<del></del>	A.	PP-4 ser.	no		
S-535 SHEET	<del></del>	<del></del>				· · · · · · · · · · · · · · · · · · ·												
1KM CM³									•			TKH	I, CW					
FREG MC	VOX SETTING	XFK BAND	DRIVER BAND	1st AMPL TUNE	. PA GRII TUNE		PA LOADING	PA LOADING SWITCH	MA, PA PLATE CURRENT	MA, PA SCREEN CURRENT				FORWARD POWER WATTS	REFLECTED POWER WATTS	ACTUAL POWER WATTS	REMARKS	
2.2									<u> </u>									
5																		
10							-									1		
20																		
30																		
NOTI	NOTE: 1. 1kW, CW, is 225 VRMS across 52 load. ITEMS ACCEPT REJECT																	
					1. A.C.	POWER TO	APP-4											
						2. A.C.	POWER TO	PS-4Å										
3. A.C. POWER TO XFK																		
					4. A.C.	4. A.C. POWER TO VOX-3												
					5. INTERLOCK CIRCUITS													
					6. KEY	6. KEY CIRCUIT (XFK)												
					7. REMOTE XMTR PLATE CIRCUIT													
					8. RECEIVER MUTING													
9.						9. 115V	ANTENNA I	RELAY										
					**			•										
												REQ. ITEM	PART NO.		DESCRIPT	ION	s	YMBOL
													O	Т	HE TECHNICA		IEL CORP.	
												SHEET 5						
SYM	C	ESCRIPTION	N	DATE CH	. NO. DRAFTS CHI	CKER ENG. APP.						MATERIAL			TEST PROCEDURE CHART, SBT-1K			
	UNLESS OTHE		CIFIED:	SCALE:								TYPE & TEMPER	HEAT TREAT, SPEC	. DRAWN	CHECKER	Konteh	HAL APPROVAL	
	IONS ARE IN INC	HES		BEEN DETE	LLOWABLE TOLE RMINED AND AN	Y DEVIATIONS		ODEL.	SECTION	ABS'Y. NO.	DATE	I I FE G IEMPER	Inca incal sec	PK	UNEUKER	S-535		Γ
FRACTIONS ± 1/64 DECIMALS ± .005 ANGLES ± 1/2°		WILL BE CAUSE FOR REJECTION. REMOVE ALL BURRS AND SHARP EDGES		PER UNIT	LL	USED C	DN		FINISH	& SPEC. NO.		P. MECH. DES, APP.	SHEET	5 of 5	1			